



5072

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1623	815822A47	GEAR HOUSING ASSEMBLY, (CO	1	(1.47:1 - 1.62:1 - 1.81:1 - 1.94:1 R.	
-	1623	815822A52	GEAR HOUSING ASSEMBLY, (CO	1	(2.00:1 Ratio)	
1	1623	815822A36	GEAR HOUSING ASSEMBLY (B.	1		
40		76865	CRANK, Shift, Shift	1		
41		818349A 1	SPOOL KIT, Shift	1		
42	15	44491A 1	SHIM SET	AR		
43		828830A 2	BEARING ADAPTOR ASSEMBL'	1		
44	31	814653	BEARING ASSEMBLY, Roller	1		
45	12	815481	THRUST WASHER,	1		
46	31	815480	BEARING, Thrust	1		
47	43	828290A 2	GEAR, Reverse	1	(1.47:1 - 1.62:1 - 1.81:1 - 1.94:1 R.	
47	43	855652A 1	GEAR, Reverse	1	(2.00:1 RATIO)	
48	31	15844	BEARING ASSEMBLY, Roller	1		
49	52	853594	CLUTCH	1		
50	17	30632	PIN, Cross	1		
51	24	30893	SPRING	1		
52	44	824111	SHAFT, Propeller	1		
53	43	828289A 1	GEAR SET, Forward -with Pinion	1	(1.47:1 - 1.62:1 - 1.81:1 - 1.94:1 R.	
53	43	855651A 1	GEAR SET, Forward/Pinion, Forw	1	(2.00:1 RATIO)	
54	31	815480	BEARING, Thrust	1		
55	23	17615 14	SPACER SHIM, (.206)	AR		
55	23	17615 15	SPACER SHIM, (.208)	AR		
55	23	17615 16	SPACER SHIM, (.210)	AR		
55	23	17615 17	SPACER SHIM, (.212)	AR		
55	23	17615 18	SPACER SHIM, (.214)	AR		
55	23	17615 19	SPACER SHIM, (.216)	AR		
55	23	17615 20	SPACER SHIM, (.218)	AR		
55	23	17615 21	SPACER SHIM, (.220)	AR		
55	23	17615 22	SPACER SHIM, (.222)	AR		
55	23	17615 23	SPACER SHIM, (.224)	AR		
55	23	17615 24	SPACER SHIM, (.226)	AR		
55	23	17615 25	SPACER SHIM, (.228)	AR		
55	23	17615 26	SPACER SHIM, (.230)	AR		
56	12	815481	THRUST WASHER,	1		
57	25	31534	O-RING	1		15
58		828831A 3	BEARING ADAPTOR ASSEMBL'	1		
59	31	814653	BEARING ASSEMBLY, Roller	1		
60	31	15842	BEARING, Thrust	2		
61	12	18448	THRUST WASHER	2		
62		818291 1	RACE, Thrust	2		
63		814653	KEEPER	2		