



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14336A31	PUMP/MOTOR ASSEMBLY	1	(Design III - Etched Manufacturing	
2		891736T	MOTOR ASSEMBLY (Complete)	1	(Design II - Etched Manufacturing	
3		891737	BRUSH KIT	1		
4		891738	HOLDER ASSEMBLY, Brushes	1		
5	10	891739	SCREW, Brush Holder	2		
6	25	891740	O-RING	1		
7		NSS	NOT SOLD SEPARATE, END I			
8	10	891741	SCREW	4		
9		NSS	NOT SOLD SEPARATE, COVE	1		
10		NSS	NOT SOLD SEPARATE, FIELD	1		
11		NSS	NOT SOLD SEPARATE, WASH	2		
12		NSS	NOT SOLD SEPARATE, ARM	1		
13		892608	CIRCUIT BOARD, Radio Frequ	1		
14		NSS	NOT SOLD SEPARATE, SCRE	2		
15	10	823444	SCREW	2		
16		808728T	ADAPTER ASSEMBLY	1		
17		803852	COUPLING	1		
18	25	89498	O-RING (Motor End)	1		
19		18529	PUMP ASSEMBLY (With Screw	1		
20	35	89496	FILTER	2		
21	25	17645	O-RING (Reservoir End)	1		
22		883166A	RESERVOIR KIT	1	(With Filters-Ref 20 And O Ring-Rc	
23	36	861597	CAP, Oil Reservoir	1	(Standard)	
23	36	865448A01	CAP, Oil Reservoir, Oil Reservo	OPT	(Rough Water Application)	
24	10	883167	SCREW, (#8-32)	4		
25		812498A	VALVE KIT, Relief (UP Pressure)	1		
26		812499A	VALVE KIT, Relief (Down Pressure	1		
27		95353A	VALVE KIT, Relief (Thermal Relief)	1		
28		18545A	REPAIR KIT (Overhaul)	1		