



IIIA SSM

18780

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1677	817090A13	GEAR HOUSING ASSEMBLY	1	(BASIC)	
2	31	19480	BEARING, Roller	2		1
3	11	19328	NUT (Special)	1		1
4	43	19329A 1	GEAR SET (Pinion and Drive)	2	(RH - 1.00:1 RATIO)	
4	43	19330A 1	GEAR SET (Pinion and Drive)	2	(LH - 1.00:1 RATIO)	
4	43	19332A 1	GEAR SET (Pinion and Drive)	2	(RH - 1.125:1 RATIO)	
4	43	19333A 1	GEAR SET (Pinion and Drive)	2	(LH - 1.125:1 RATIO)	
5	45	816265	DRIVESHAFT (Rear)	1		
6	15	39808A 1	SHIM ASSEMBLY	AR		
7	11	19327	NUT (Special)	1		1
8	45	818552	DRIVESHAFT (Front)	1		
9	31	35990A 2	BEARING ASSEMBLY, Roller	2		1
10	23	39816	SPACER	2		
11		19326	RETAINER	1		
12	10	39826	SCREW, (.313-18 X 1)	7		1
13	43	18987	GEAR, Spur (Rear)	1		
14	12	19479	WASHER	1		1
15	11	61315	NUT (Special)	1		1
16	43	18986	GEAR, Spur (Front)	1		
17	12	817260	WASHER	1		
18	11	19475	NUT (Special)	1		1
-	1677	817090A10	REBUILD KIT	1		