



18795

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		69112A 2	BELL HOUSING ASSEMBLY	1		
2	17	48450	PIN, Dowel	2		
3	25	31534	O-RING	1		
4	16	57987	STUD (.625-18 x 4.310)	6		
5	12	47428	WASHER	6		
6	11	47379	NUT, (.625-18)	6		
7		48124	GUIDE, Valve	1		
8	27	48363	GASKET, Valve Guide	1		
9	25	48452	QUAD RING	1		
10	20	48219	CHECK VALVE	1		
11	24	48442	SPRING	1		
12		48163A 1	COVER ASSEMBLY, Valve Guide	1		
13	22	47841	FITTING, (.375-18 x .500)	1		
14	27	48363	GASKET, Valve Guide	1		
15	10	36154	SCREW, (.250-28 x 1.380)	4		
16	13	26992	LOCKWASHER, (.250)	4		
17	32	48458	HOSE	1		
18	54	18076 1	CLAMP, Worm Gear	2		
19		47370A 1	BELLOWS	1		
20	54	59381	CLAMP	2		
21		70704A 1	HOUSING ASSEMBLY, Gimbal	1		
22	16	57988	STUD GIMBAL HOUSING TO TF	8		
23	27	47366	GASKET, Gimbal Housing	1		
24	31	30457	BEARING (Lower)	1		
25	26	31851	OIL SEAL	2		
26	31	21638	BEARING (Upper)	1		
27	26	32121	OIL SEAL	1		
28	22	74036	FITTING, Grease	1		
29	19	77633	LUBRICAP	1		
30	37	13682 11	DECAL	1		
31	22	47841	FITTING, (.375-18 x .500)	1		
32	16	56766	STUD, (.250-20/.250-28 x 1.380)	2		
33		34762A 1	PLATE ASSEMBLY	1		
34	10	34763	SCREW, (#12-24 x 0.75)	2		
35	22	38565	FITTING, (.375-18)	1		
36	32	93315 12	HOSE (20.500 In.)	1		
37	54	18076 1	CLAMP, Worm Gear	2		
38		47347	CONNECTOR	1		
39	27	47644	GASKET	1		
40	11	35888	NUT, (.250-28)	2		
41	17	91464F	PIN, Swivel	1		