



18770

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1567	8942A	DRIVESHAFT HOUSING ASSEMB	1		
2	16	57985	STUD (2.810)	6		
3	26	38105	OIL SEAL	1		1
4	16	57932	STUD, (.375-16/.375-24 x 1.750)	7		
5	37	14489A87	DECAL SET	1		1
6	16	57984	STUD, (.437-14/.437-20 x 2.380)	2		
6	16	57983	STUD (.437-20 x 2.875)	2		
7	10	79953	SCREW, (.375-16 x .250)	1		
8	12	19183	WASHER, Fiber	1		
9	19	47579	PLUG	1		
10	43	47309A	GEAR ASSEMBLY	1	(PINION AND DRIVE) (1.00:1 RA	
10	43	813942A	GEAR SET	1	(PINION AND DRIVE) (1.18:1 RA	
10	43	87825A	GEAR SET	1	(PINION AND DRIVE) (1.25:1 RA	
10	43	64973A	GEAR SET	1	(PINION AND DRIVE) (1.33:1 RA	
10	43	92849A	GEAR SET	1	(PINION AND DRIVE) (1.40:1 RA	
10	43	813943A	GEAR SET	1	(PINION AND DRIVE) (1.50:1 RA	
11	15	34800A	SHIM ASS'Y	AR		
12	31	34804A	TAPERED ROLLER BEARING AS:	1		
13	23	47285	SPACER	1		
14	12	47451	WASHER	1		
15	11	47449	NUT (Special)	1		1
16		47303	ADAPTOR	1		
17	12	47289	WASHER	1		
18		47304	RETAINER	1		
19	11	47302	NUT, (.562-18)	1		
19	11	34933	NUT, (.437-20)	1		
20		58619A	COVER ASSEMBLY (Front)	1		
21	26	48443	OIL SEAL	1		
22	25	26722	O-RING	1		
23	27	48407	GASKET	1		
24	24	48442	SPRING	1		
25	20	48219	CHECK VALVE	1		
26	25	48452	QUAD RING	1		
27	10	47658	SCREW (.437-14 x 1.500)	2		
28	13	47659	LOCKWASHER, (.437)	2		
29	11	34863	NUT, (.375-24)	7		
30		44253A	UNIVERSAL JOINT ASSEMBLY	1		
31		44271	YOKE (Driven End)	1		
32		48153	CROSS AND BEARING ASSEMB	2		1
33		63575	SOCKET	1		
34		44252	YOKE (Driving End)	1		