



18782

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	3509	812421A 2	DRIVESHAFT HOUSING ASSEMB	1	
2	22	56800	PLUG, Pipe (.0625-27)	1	
3	16	57985	STUD (2.810)	6	
4	26	38105	OIL SEAL	1	1
5	37	14489A87	DECAL SET	1	1
6	16	13208	STUD	4	
7	10	14834	SCREW, (.735-16), Vent (.375-16) [1	
8	12	19183	WASHER, Fiber	1	
9	43	813803A 3	GEAR SET (Pinion and Drive)	1	(1.00:1 RATIO)
9	43	813804A 3	GEAR SET (Pinion and Drive)	1	(1.18:1 RATIO)
9	43	87825A 2	GEAR SET (Pinion and Drive)	1	(1.25:1 RATIO)
9	43	64973A 3	GEAR SET (Pinion and Drive)	1	(1.33:1 RATIO)
9	43	92849A 2	GEAR SET (Pinion and Drive)	1	(1.40:1 RATIO)
9	43	12407A 1	GEAR SET (Pinion and Drive)	1	(1.50:1 RATIO)
10	15	34800A 1	SHIM ASS'Y	AR	
11	31	34804A 4	TAPERED ROLLER BEARING AS:	1	
12	23	47285	SPACER	1	
13	12	47451	WASHER	1	
14	11	47449	NUT (Special)	1	1
15		47303 1	ADAPTOR	1	
16	12	47289	WASHER	1	
17		47304	RETAINER	1	
18	11	47302	NUT, (.562-18)	1	
19	24	48442	SPRING	1	
20	20	48219	CHECK VALVE	1	
21	25	48452	QUAD RING	1	
22	27	66925 1	GASKET	1	1
23		12701A 1	VALVE GUIDE ASSEMBLY	1	
24	26	66301	OIL SEAL	1	1
25	25	33145	O-RING, (1.984 x .139)	1	1
26	10	56786	SCREW, (#8-32 X .75)	3	
27		44253A 1	UNIVERSAL JOINT ASSEMBLY	1	
28		44271	YOKE (Driven End)	1	
29		48153	CROSS AND BEARING ASSEMB	2	1
30		63575	SOCKET	1	
31		44253	YOKE (Driving End)	1	
32	15	36178A 1	SHIM SET	AR	
33	31	39908A 1	TAPERED ROLLER BEARING AS:	1	
34	23	47305	SPACER	1	
35	31	34804A 3	TAPERED ROLLER BEARING AS:	1	
36	15	34822A 1	SHIM SET	AR	