



**IV SSM**

18785

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1664	9295A 5	GEAR HOUSING ASSEMBLY	1	(BASIC)	
2	31	68290A 1	BEARING, Roller	2		1
3	11	31538	NUT (.750-16)	1		1
4	43	16769A 1	GEAR SET (Pinion and Drive)	1	(RH - 1.00:1 RATIO)	
4	43	16768A 1	GEAR SET (Pinion and Drive)	1	(LH - 1.00:1 RATIO)	
4	43	78096A 1	GEAR SET (Pinion and Drive)	1	(RH - 1.125:1 RATIO)	
4	43	78095A 1	GEAR SET (Pinion and Drive)	1	(LH - 1.125:1 RATIO)	
5	45	11380A 1	DRIVESHAFT (Rear)	1		
6	15	39808A 1	SHIM ASSEMBLY	AR		
7	31	39775A 2	BEARING ASSEMBLY, Roller	1		
8	23	39816	SPACER	1		
9	11	39831	NUT (Special)	1		1
10	45	11352	DRIVESHAFT (Front)	1		
11	31	35990A 2	BEARING ASSEMBLY, Roller	1		
12	23	39816	SPACER	1		
13		39804	RETAINER	1		
14	10	39826	SCREW, (.313-18 X 1)	7		1
15	43	12352	GEAR, Spur (Driven End)	1		
16	12	39820	WASHER	1		1
17	11	53062	NUT	1	(32 THREADS PER INCH)	1
17	11	61315	NUT	1	(16 THREADS PER INCH)	1
18	43	12351	GEAR, Spur (Driving End)	1		
19	12	56042	WASHER	1		1
20	11	85361	NUT (1.375-16)	1		1
-	1664	8509A13	REBUILD KIT	1		