



1719

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		864592T02	THERMOSTAT HOUSING	1		
2	22	32803	PLUG, Pipe - Brass (.375-18)	2		
3		806490T	SENDER, Water Temperature	1		
4	13	26996	LOCKWASHER, (#10)	1		
5	11	68219	NUT, (#10-32)	1		
6		805218T	SENSOR	1		
7	27	806871	GASKET, Thermostat Housing	1		2
8		807252T 2	THERMOSTAT, 160 Degrees	1		
9	23	806922	SLEEVE, Thermostat	1		
10	27	53045 1	GASKET, Lower Thermostat Housi	1		2
11	10	98508	SCREW, (.375-16 x 3.00)	2		
12		12552	LIFTING EYE	1		
13	22	98477A 2	VALVE ASSEMBLY, Tee	1		
14	30	98475	BALL, Nylon	2		
15	24	75533	SPRING	2		
16	12	89302	WASHER, (.203 x .406 x .040)	2		
17	10	98476	SCREW, (#10-32 x 6.00)	1		
18	11	826709106	NUT, (#10-32)	1		
-	27	807670A96	GASKET/SEAL SET, Engine Overl	1		