



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		805597A	1 BRACKET-REAR	2		
2	10	37269	SCREW (7/16-14 X 2 IN.)	2		
2	10	91903	SCREW (7/16-14 X 1-3/4 IN.)	2		
3	13	32993	LOCKWASHER (7/16 IN.)	4		
4	10	37269	SCREW (7/16-14 X 2 IN.)	2		
5	13	32993	LOCKWASHER (7/16 IN.)	2		
6	11	29553	NUT (7/16-14)	2		
7		71128A	2 BRACKET-FRONT	2		
8	10	68101	SCREW (3/8-16 X 1-3/8 IN.)	2		
9	16	805357	STUD	4		
10	10	57357	SCREW (7/16-14 X 2-1/4 IN.)	2		
11	13	32993	LOCKWASHER (7/16 IN.)	2		
12	11	29553	NUT (7/16-14)	2		
13		806698	5 TRUNNION	4		
14	13	68102	LOCKWASHER	4		
15		66284A	2 BASE ASSEMBLY-ENGINE	2		
16	11	20739	NUT JAM (3/4-16)	2		
17	14	66658	WASHER-TAB	2		
18		816326A	2 BASE ASSEMBLY-TRANSMISSIOI	2		
19	16	816327	STUD	2		
20		47656	MOUNT	4		
21	12	48611	WASHER	4		
22	11	816331	NUT JAM (3/4-16)	2		
23	14	66658	WASHER-TAB	2		
24	11	20739	NUT JAM (3/4-16)	4		
25	54	78945	CLAMP	1		