



2274

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	32	863611	HOSE, Sea Water Pump to Transm	1		
2	32	860089	HOSE, Molded, Transmission Cooler	1		
3	32	808033	HOSE, Molded, Fuel Cooler to Ther	1		
4	32	861590A05	HOSE ASSEMBLY, Circulation Pump	1		
5	32	864979	HOSE	1	(Inline)	
5	32	863813	HOSE, Tee Fitting to Port Elbow	1	(V-Drive)	
6	32	864979	HOSE, Tee Fitting to Starboard Elb	1	(Inline)	
6	32	863813	HOSE, Tee Fitting to Starboard Elb	1	(V-Drive)	
7	32	807697	HOSE, Thermostat Housing to Start	1		
8	32	862139	HOSE, Thermostat Housing to Port I	1		
9	32	863343	HOSE, Water Pickup to Seawater F	1		
10	22	862210A01	ELBOW KIT, Drain	2		
11	22	806608A	PLUG KIT, Blue	1		
12	25	62706	O-RING, (.426 x .070)	1		
13	22	860088	BUSHING	1		
14	22	46982	FITTING, (90 Degree)	1		
15	54	815504216	CLAMP, Worm Gear, Hose	AR		
16	54	815504222	CLAMP, Worm Gear, Hose	AR		
17	54	815504232	CLAMP, Worm Gear, Hose	AR		
18	54	47715	CLIP, Hose	1		
19	11	29250	NUT, (.312-24)	1		
NS	19	807992	COVER, Hose Clamp End	AR		