



A = USE WITH RISER KITS

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		860246A10	MANIFOLD ASSEMBLY-EXHAUST	1		
2	22	42861 1	PLUG-PIPE (3/4-14)	4		
3	27	33395	GASKET	2		2
4	10	53728	SCREW (3/8-16 X 4-5/8 IN.)	8		
5	27	863724	GASKET	2		
6	22	806926A 1	ELBOW-DRAIN	2		
7	22	806608A 1	PLUG-DRAIN	2		
8	25	62706	QUAD RING	2		2
9		807988A 2	ELBOW ASSEMBLY-EXHAUST	2		
10	22	42861 1	PLUG-PIPE (3/4-14)	2		
11	22	73379	PLUG-PIPE (1/4-18)	2	(COMPONENT OF 807988A2 ELE	
12	10	43749	SCREW (3/8-16 X 5-3/4 IN.)	8	(350)	
12	10	43749	SCREW (3/8-16 X 5-3/4 IN.)	6	(6.2L)	
12	10	44387	SCREW (3/8-16 X 6-3/4)	2	(6.2L)	
13		807153T	PIPE-EXHAUST	2	(STANDARD)	
14		807611T	PIPE-EXHAUST	2	(OPTIONAL)	
15	32	44348T	TUBE-EXHAUST	2		
16	54	815504272	CLAMP	8		
17		93320A 5	RISER EXTENSION KIT (3.)	1	(EACH KIT CONTAINS 2 RISERS	
17		93322A 7	RISER EXTENSION KIT (6.)	1	(EACH KIT CONTAINS 2 RISERS	
18	22	41622	PLUG-PIPE (3/4-14)	2		
19	22	32802 2	PLUG-PIPE (1/8-27)	2		
20	27	863726	GASKET	2		
21	12	46132	WASHER	8	(USE WITH 3 IN. RISER)	
22	11	46335	NUT (3/8-24)	8	(USE WITH 3 IN. RISER)	
23	16	11375	STUD (3/8 X 9-3/8 IN.)	8	(USE WITH 3 IN. RISER)	
24	10	12244	SCREW (3/8-16 X 1 IN.)	8	(USE WITH 6 IN. RISER)	
25		818598T	BRACKET-RISER	1	(USE WITH 6 IN. RISER)	
26	10	76596	SCREW (1/4-20 X 1-1/4 IN.)	3	(USE WITH 6 IN. RISER)	
27	23	806981	SPACER	6	(USE WITH 6 IN. RISER)	
28	12	35462	WASHER	3	(USE WITH 6 IN. RISER)	
29	11	64015	NUT (1/4-20)	3	(USE WITH 6 IN. RISER)	
30	22	37372	PIPE PLUG (1/2-14)	2		
31		861242	BRACKET	1	(6.2L)	
-	27	807670A96	GASKET SET-ENGINE OVERHAU	1		