



A = TO FUEL RAIL  
 B = TO INTAKE MANIFOLD

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		807951T	BRACKET-FUEL COOLER	1	
2		807685T	INSULATOR-BASE	1	
3		861156A 1	FUEL PUMP	1	
4	22	807783A 1	FITTING ASSEMBLY (90 DEG.)	1	
5	25	805063	O-RING	4	2
6	22	808001A 1	FITTING ASSEMBLY	1	
7	25	805062	O-RING	1	2
8		861267A 1	COOLER-FUEL	1	
9	10	861303	SCREW	1	
10	53	861414	RING-RETAINING	1	
11	22	806608A 1	PLUG-DRAIN	1	
12	25	62706	QUAD RING	1	2
13		807979T	PLATE	1	
14	11	29598	NUT (1/4-28)	2	
15		807952A 1	REGULATOR-FUEL PRESSURE	1	
16	35	805406	FILTER-FUEL PRESSURE REGI	1	
17	10	852368	SCREW (#10-24 X 3/4 IN.)	2	
18	12	89302	WASHER	2	
19	22	808002A 1	FITTING ASSEMBLY	1	
20	12	36533	WASHER	1	
21	32	806173 79	HOSE (BULK 46 IN. HOSE)	1	(CUT TO 9 IN.)
22	22	860273	CONNECTOR-HOSE	1	
23	10	808005	SCREW (1/4-20 X 1/2 IN.)	4	
24		26901 1	BUMPER-RUBBER	8	
25		807930	INSULATOR-COVER	1	
26		861567A 2	FUEL LINE-FUEL COOLER TO FU	1	(Use w/ 2 Orings)
26	32	862617A01	FUEL LINE-FUEL COOLER TO FU	1	(USE W/ 1 SEAL)
27	26	863151	SEAL	1	
27	25	805063	O-RING	2	2
28	11	860069	NUT (3/8-16)	2	
29	32	806173 79	HOSE (BULK 46 IN. HOSE)	1	
30	54	816311T	CABLE TIE	AR	
-	27	807670A96	GASKET SET-ENGINE OVERHAU	1	