



- A - Audio Warning System**  
 1 - Oil Pressure Switch  
 2 - Transmission Fluid Temperature Switch
- B - Instrumentation System**  
 1 - Oil Pressure Sender  
 2 - Water Temperature Sender
- C - Charging And Starting System**  
 1 - Alternator  
 2 - Ground Stud  
 3 - Starter  
 4 - Circuit Breaker  
 5 - Starter Slave Solenoid  
 6 - Neutral Safety Switch
- a - Harness Connector  
 b - Positive (+) Power Wire to EFI Harness  
 c - Auxiliary Tachometer Lead

90 Amp  
 System  
 Fuse



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-	84	808035A	2 WIRING HARNESS-ENGINE	1	(Use With Mando Alternator With V	
-	84	861820T	7 WIRING HARNESS-ENGINE	1	(Use With Delco Alternator With M	