



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		14336A 8	PUMP ASSEMBLY-POWER TRIM	1	(SEE "HYDRAULID PUMP" FOR	
2	84	79138A 9	CABLE ASSEMBLY-BATTERY	1	(BLACK - NEGATIVE)	
3	10	90285	SCREW (5/16-18 X 5/8 IN.)	1		
4	12	56720	WASHER	1		
5	11	68292	NUT (5/16-18)	1		
6	84	79147A 3	HARNESS ASSEMBLY	1		
7	88	79091	FUSE (20 AMP.)	1		
8	84	95084A 2	CABLE ASSEMBLY	1		
9		88075	RETAINER	1		
10	89	96158	SOLENOID	2		
11	10	41508	SCREW (1/4-20 X 1/2 IN.)	4		
12	11	26419	NUT(#8-32)	4		
13	13	26992	LOCKWASHER (1/4 IN.)	4		
14	11	94330	NUT (1/4-20)	4		
15	85	96535	BOOT	1		
16	10	48409	SCREW (#10-16 X 5/8 IN.)	1		
17		94275	CONNECTOR	1		
18	84	86322A15	CABLE ASSEMBLY (BLACK) (5-1/2	2		
19	84	79139A12	CABLE ASSEMBLY-BATTERY	1	(RED - POSITIVE)	
20	88	79023A10	FUSE (110 AMP.)	1		
21	12	96457	WASHER	1		
22	11	21825	NUT (1/4-28)	1		
23		42419A 1	BRACKET ASSEMBLY (FLOOR M(1		
24		58491	BUMPER	2		
25	10	59784	SCREW (1/4-10 X 1 IN.)	6		
26	12	29245	WASHER	6		
27	10	35386	SCREW (5/16-18 X 1 IN.)	4		
28	13	39107	LOCKWASHER (5/16 IN.)	4		
29	84	86322A24	CABLE ASSEMBLY (BLACK) (4 IN.	1		
.		14336A 9	COMPLETE HYDRAULIC PUMP	1	(INCLUDES ALL PARTS ON THIS	