

### DRIVE UNIT CHART

ITEM #1: For replacement of Drive Shaft Housing Assembly, Complete which includes gears, universal joints, etc., order:

Δ1589-8868A32	1.65:1 RATIO	BRAVO I
Δ1589-8868A14	1.50:1 RATIO	
Δ1589-8868A27	1.36:1 RATIO	
Δ1589-8868A21	1.36:1 RATIO	BRAVO II
Δ1589-8868A29	2.00:1 RATIO	
Δ1589-8868A14	2.00:1 RATIO	
Δ1589-8868A27	1.81:1 RATIO	BRAVO III
Δ1589-8868A21	1.81:1 RATIO	
Δ1589-8868A29	2.20:1 RATIO	
●1589-8868A32	2.00:1 RATIO	BRAVO III
●1589-8868A50	2.00:1 RATIO	
●1589-8868A51	1.81:1 RATIO	
Δ1589-8868A50	1.65:1 RATIO	BRAVO III
Δ1589-8868A50	1.50:1 RATIO	

Ω = See Note #1 Below  
 Δ = See Note #2 Below

ITEM #2: For replacement of Drive Shaft Housing Assembly, Complete and Gear Housing Assembly, Complete, order:

GAS	5-5120165EP	1.65:1 RATIO	BRAVO I
	5-5120150DP	1.50:1 RATIO	
	5-5120136DP	1.36:1 RATIO	
GAS	5-5220200DP	2.00:1 RATIO	BRAVO II
	5-5220181DP	1.81:1 RATIO	
	5-5220220EP	2.20:1 RATIO	
GAS	●5-5D30220GP	2.20:1 RATIO	BRAVO III
	5-5D30200FP	2.00:1 RATIO	
	●5-5D30181GP	1.81:1 RATIO	
DIESEL	5-5D30165GP	1.65:1 RATIO	BRAVO III
	5-5D30150GP	1.50:1 RATIO	
	●5-5D33181GP	1.81:1 RATIO	

ITEM #3: For replacement Gear Housing Assembly, Complete, order:

1656-8866A10	BRAVO I - SEE NOTE #3 BELOW	BRAVO III
1656-8866A15	BRAVO II - SEE NOTE #4 BELOW	
1641-8294A7	BRAVO II - SEE NOTE #4 BELOW	
1641-8294A16	2.20:1/2.00:1/1.81:1 RATIO (8 HOLE WATER PICKUP)	BRAVO III
1656-8866A20	SEE NOTE #5 BELOW	
1656-8866A32	1.81:1 RATIO	BRAVO III
1656-8866A24	1.65:1 RATIO	
1656-8866A19	1.50:1 RATIO	

ITEM #4: For replacement Gimbal Housing Assembly, Complete, which includes bell housing, gimbal ring, trim cylinder, etc. order:

6-602000FP (round oil bottle)	WITH TRIM SENDERS
6-6020010GP (square oil bottle)	WITHOUT TRIM SENDERS
6-6020004GP (round oil bottle)	WITHOUT TRIM SENDERS
NOTE #1: Use with Casting #1589-8867C, C2, C3 or C5S	
NOTE #2: Use with Casting #1589-8867C5	
NOTE #3: 1656-8866A10 (Use with Casting #1656-8865C, C1, or C2S) 1656-8866A15 (Use with Casting #1656-8865C2)	
NOTE #4: 1641-8294A7 (Use with Casting #1641-8293C or C2S) 1641-8294A16 (Use with Casting #1641-8293C2)	
NOTE #5: 1656-8866A20 (Use with casting #1656-8865C10)	
NOTE #6: 1656-8866A32 (Use with casting #1656-8865C15) 1656-8866A24 (Use with casting #1656-8865C15) 1656-8866A19 (Use with casting #1656-8865C15)	

REVISED MARCH 1994

\*BRAVO\*

PAGE 1

### Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
0	1589	8868A52	DRIVESHAFT HOUSING (1.65:1 R	1	(BRAVO I)	1,2
0	1589	8868A14	DRIVESHAFT HOUSING (1.50:1 R	1	(BRAVO I)	5,2
0	1589	8868A50	DRIVESHAFT HOUSING (1.50:1 R	1	(BRAVO I)	1,2
0	1589	8868A21	DRIVESHAFT HOUSING (1.36:1 R	1	(BRAVO I)	7,2
0	1589	8868A51	DRIVESHAFT HOUSING (1.36:1 R	1	(BRAVO I)	1,2
0	1589	8868A14	DRIVESHAFT HOUSING (2.00:1 R	1	(BRAVO II)	5,2
0	1589	8868A50	DRIVESHAFT HOUSING (2.00:1 R	1	(BRAVO II)	7,2
0	1589	8868A21	DRIVESHAFT HOUSING (1.81:1 R	1	(BRAVO II)	7,2
0	1589	8868A51	DRIVESHAFT HOUSING (1.81:1 R	1	(BRAVO II)	1,2
0	1589	8868A52	DRIVESHAFT HOUSING (2.20:1 R	1	(BRAVO II)	1,2
0	1589	8868A50	DRIVESHAFT HOUSING (2.00:1 R	1	(BRAVO II)	1,2
0	1589	8868A51	DRIVESHAFT HOUSING (1.81:1 R	1	(BRAVO III)	1,2
0	1589	8868A50	DRIVESHAFT HOUSING (1.65:1 R	1	(BRAVO III)	1,2
0	1589	8868A50	DRIVESHAFT HOUSING (1.50:1 R	1	(BRAVO III)	1,2
0	5	5120165EP	DRIVESHAFT/GEAR HSG (1.65:1	1	(BRAVO I) (GAS)	14
0	5	5120150DP	DRIVESHAFT/GEAR HSG (1.50:1	1	(BRAVO I) (GAS)	14
0	5	5120136DP	DRIVESHAFT/GEAR HSG (1.36:1	1	(BRAVO I) (GAS)	14
0	5	5220200DP	END MODEL, BRAVO STERN DR	1	(BRAVO II) (GAS)	14
0	5	5220181DP	END MODEL, BRAVO STERN DR	1	(BRAVO II) (GAS)	14
0	5	5220220EP	DRIVESHAFT/GEAR HSG (2.20:1	1	(BRAVO II) (GAS)	14
0	5	5D30220GP	DRIVESHAFT/GEAR HSG (2.20:1	1	(BRAVO III) (GAS)	14
0	5	5D30200FP	DRIVESHAFT/GEAR HSG (2.00:1	1	(BRAVO III) (GAS)	14
0	5	5D30181GP	DRIVESHAFT/GEAR HSG (1.81:1	1	(BRAVO III) (GAS)	14
0	5	5D30165GP	DRIVESHAFT/GEAR HSG (1.65:1	1	(BRAVO III) (DIESEL)	14
0	5	5D30150GP	DRIVESHAFT/GEAR HSG (1.50:1	1	(BRAVO III) (DIESEL)	14
0	5	5D33181GP	DRIVESHAFT/GEAR HSG (1.81:1	1	(BRAVO III) (DIESEL)	14
0	1656	8866A10	GEAR HOUSING	1	(BRAVO I)	5
0	1656	8866A15	GEAR HOUSING ASSEMBLY	1	(BRAVO I)	5,6,2
0	1641	8294A7	GEAR HOUSING	1	(BRAVO II)	3,15
0	1641	8294A16	GEAR HOUSING ASSEMBLY	1	(BRAVO II)	4,15
0	1641	8866A20	GEAR HOUSING, 8 Hole Water Pk	1	(BRAVO III)	16,15
0	1656	8866A32	GEAR HSG, 9 Hole Water Pickup (	1	(BRAVO III)	17,10,15
0	1656	8866A24	GEAR HSG, 9 Hole Water Pickup (	1	(BRAVO III)	10,15
0	1656	8866A19	GEAR HSG, 9 Hole Water Pickup (	1	(BRAVO III)	10,19,15
0	6	6020000FP	GIMBAL HSG, Round Oil Bottle W/	1		20
0	6	6020010GP	GIMBAL HSG, Square Bottle With	1		20
0	6	6020004GP	GIMBAL HSG, Round Oil Bottle W/	1		20