



18721

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	1589	8868G21	DRIVESHAFT HOUSING ASSEMB	1		
2	16	57920	3 STUD, (.437-14/.437-20 x 2.060)	4		
3		16755A	1 SEAL	1		3
4	25	45710	O-RING, (1.424 x .103)	1		3
5	31	815900	BEARING	1		
6	31	87156	BEARING ASSEMBLY, Roller	1		
7	25	62705	O-RING	1		3
8	23	861209A	1 BUSHING KIT	1		
9	26	12709	SEAL, Oil	1		3
10	22	67892A	1 FITTING KIT, Plug Fill/Drain	1		
11	12	19183	WASHER, Fiber	1		3
12		92068A	6 TOP COVER	1		
13	31	815900	BEARING	1		
14	31	87156	BEARING ASSEMBLY, Roller	1		
15	25	97387	O-RING	1		3
16	10	98794	SCREW, (.375-16 x 1.00)	4		
17	23	87560091	THRUST BEARING, (.091)	AR	(RED)	6
17	23	87560094	THRUST BEARING, (.094)	AR	(LIGHT BLUE)	6
17	23	87560097	THRUST BEARING, (.097)	AR	(GREEN)	6
18	24	17997A	1 SPRING KIT	1		3
19	31	86771	BEARING, Thrust	2		
20	43	807436A	6 GEAR (1.50:1 BRAVO I) (1.65:1 BF	2	(32 TEETH - MATES WITH 27 TC	
20	43	807436A	7 GEAR (1.50:1 BRAVO III)	2	(32 TEETH - MATES WITH 27 TC	
20	43	807438A	5 GEAR (1.36:1 BRAVO I)	2	SN# 0K103438 & Below	
20	43	807438A	5 GEAR (1.36:1 BRAVO III & 1.50:1 E	2	SN# 0K262209 & Below	
20	43	807438A	5 GEAR (1.81:1 BRAVO II & III)	2		
20	43	807438A	6 GEAR (1.36:1 BRAVO I)	2	SN# 0K103439 & Up	
20	43	807438A	6 GEAR (1.36:1 BRAVO III & BRAVO	2	SN# 0K262210 & Up	
20	43	807437A	5 GEAR (1.65:1 BRAVO I) (2.20:1 BF	2	(30 TEETH - MATES WITH 23 TC	
21	31	86768A	2 THRUST BEARING ASSEMBLY	1		
22	52	807375A	1 CLUTCH AND CAM KIT	1	(Refer to Service Bulletin 2001-17	
22	52	807375A	2 CLUTCH ASSEMBLY	1	(Refer to Service Bulletin 2001-17	
23		N.S.S.	Not Sold Seperate, Spring	2	SN# 0K090999 & Below	
23	24	93505	SPRING	2	SN# 0K091000 & Up	
24	45	812773T	DRIVESHAFT	1		
25	23	86770	COLLAR	1		
26		97351	KEEPER	2		3
27	19	32297	PLUG	1		
28	12	91964	WASHER	4		
29	11	35053	NUT, (.437-20)	4		
30		90800F	1 INSERT, Trim Adjustment	1		