



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		14336A 8	PUMP/MOTOR ASSEMBLY	1		
2	84	79138A 9	CABLE ASSEMBLY, Black, Battery	1		
3	10	90285	SCREW, (.312-18 x .625)	1		
4	12	56720	WASHER, (.330 x .750 x .060)	1		
5	11	68292	NUT, (.312-18)	1		
6	84	79147A 3	HARNESS ASSEMBLY	1		
7	88	79091	FUSE, (20 Ampere)	1		
8	84	95084A 2	CABLE ASSEMBLY	1		
9		88075	RETAINER	1		
10	89	96158	SOLENOID STARTER	2		
11	10	41508	SCREW, (.250-20 x .500)	4		
12	11	26419	NUT, (#8-32)	4		
13	13	26992	LOCKWASHER, (.250)	4		
14	11	94330	NUT, (.250-20)	4		
15	85	96535	BOOT	1		
16	10	48409	SCREW, (#10-16 x .625)	1		
17		94275	LINK	1		
18	84	86322A15	CABLE ASSEMBLY, (5.50 Inches)	2		
19	84	79139A12	CABLE ASSEMBLY, Red, Battery	1		
20	88	79023A10	FUSE ASSEMBLY, (110 Ampere)	1		
21	12	96457	WASHER	1		
22	11	21825	NUT, (.250-28)	1		
23		42419A 1	BRACKET ASSEMBLY, Floor Mour	1		
24		58491	CHANNEL, Rubber (4.00 Inches)	2		
25	10	59784	SCREW, (.250-10 x 1.00)	6		
26	12	29245	WASHER, (.281 x .500 x .060)	6		
27	10	90271	SCREW, (.375-16 x .62)	2		
28	13	58643	LOCKWASHER, (.375)	2		
29	84	86322A24	CABLE ASSEMBLY, (4.00 Inches)	1		
30		14336A 9	PUMP ASSEMBLY, Trim, Includes.	1		