

Diesel

Model	Ref. No.	Ratio	Driveshaft Housing			Gear Housing		
			Gear Tooth Count	Gear Set Part Number	Driveshaft Housing Complete	Gear Tooth Count	Gear Set Part Number	Gear Housing Complete
Bravo One X								
Bravo One X w/DWP	1	1.36:1	29/27	43-858331A3	1589-8868H81	15/19	43-14063A1	1656-8866A63
Bravo One X w/DWP	2	1.50:1	32/27	43-858327A3	1589-8868H82	15/19	43-14063A1	1656-8866A63
Bravo One X w/DWP	3	1.65:1	30/23	43-858335A3	1589-8868H86	15/19	43-14063A1	1656-8866A63
Bravo Two X								
Bravo Two X	4	1.50:1	29/27	43-858331A3	1589-8868H81	18/25	(P)43-827304T (D)43-827303	1641-8294A19
Bravo Two X	5	1.65:1	32/27	43-858327A3	1589-8868H82	18/25	(P)43-827304T (D)43-827303	1641-8294A19
Bravo Two X	6	1.81:1	29/27	43-858331A3	1589-8868H81	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
Bravo Two X	7	2.00:1	32/27	43-858327A3	1589-8868H82	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
Bravo Two X	8	2.20:1	30/23	43-858335A3	1589-8868H86	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
Bravo Three X								
Bravo Three X	9	1.36:1	29/27	43-858331A3	1589-8868H81	15/19	43-805448A1	1656-8866A37
Bravo Three X	10	1.50:1	32/27	43-858327A3	1589-8868H82	15/19	43-805448A1	1656-8866A37
Bravo Three X	11	1.65:1	32/27	43-858327A3	1589-8868H82	18/25	43-824517A1	1656-8866A36
Bravo Three X	12	1.81:1	29/27	43-858331A3	1589-8868H81	16/27	43-822535A1	1656-8866A35
Bravo Three X	13	2.00:1	32/27	43-858327A3	1589-8868H82	16/27	43-822535A1	1656-8866A35
Bravo Three X	14	2.20:1	30/23	43-858335A3	1589-8868H86	16/27	43-822535A1	1656-8866A35
Bravo Three X	15	2.43:1	30/23	43-858335A3	1589-8868H86	13/24	43-828336A1	1656-8866A51

1609

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
-			NS NOT SHOWN, Bravo One X	-		
1	5	5232100NZ	END MODEL, Diesel Bravo I x 1.3	1	(Bravo One X) (With DWP) (1.36:1	
1	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
1	43	858331A 3	GEAR SET, (29/27)	1		
1	1656	8866A63	GEAR HOUSING ASSEMBLY, C	1		
1	43	14063A 1	GEAR SET, (15/19)	1		
2	5	5232200NZ	END MODEL, Diesel Bravo I x 1.5	1	(Bravo One X) (With DWP) (1.50:1	
2	1589	8868H82	DRIVESHAFT HOUSING ASSEM	1		
2	43	858327A 3	GEAR SET, (32/27)	1		
2	1656	8866A63	GEAR HOUSING ASSEMBLY, C	1		
2	43	14063A 1	GEAR SET, (15/19)	1		
3	5	5232300NZ	END MODEL, Diesel Bravo I x 1.6E	1	(Bravo One X) (With DWP) (1.65:1	
3	1589	8868H86	DRIVESHAFT HOUSING ASSEM	1		
3	43	858335A 3	GEAR SET, (30/23)	1		
3	1656	8866A63	GEAR HOUSING ASSEMBLY, C	1		
3	43	14063A 1	GEAR SET, (15/19)	1		
-			NS NOT SHOWN, Bravo Two X	-		
4		5332200NP	, Complete	1	(Bravo Two X) (1.50:1 Ratio)	
4	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
4	43	858331A 3	GEAR SET, (29/27)	1		
4	1641	8294A19	GEAR HOUSING ASSEMBLY, C	1		
4	43	827304T	GEAR, (18/25)	1		
4	43	827303	GEAR, DRIVE (18/25)	1		
5		5332300NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (1.65:1 Ratio)	
5	1589	8868H82	DRIVESHAFT HOUSING ASSEM	1		
5	43	858327A 3	GEAR SET, (32/27)	1		
5	1641	8294A19	GEAR HOUSING ASSEMBLY, C	1		
5	43	827304T	GEAR, (18/25)	1		
5	43	827303	GEAR, DRIVE (18/25)	1		
6		5337400NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (1.81:1 Ratio)	
6	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
6	43	858331A 3	GEAR SET, (29/27)	1		
6	1641	8294A16	GEAR HOUSING ASSEMBLY, C	1		
6	43	41656T	GEAR, (16/27)	1		
6	43	41657T	GEAR, DRIVE (16/27)	1		
7		5337600NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (2.00:1 Ratio)	
7	1589	8868H82	DRIVESHAFT HOUSING ASSEM	1		
7	43	858327A 3	GEAR SET, (32/27)	1		
7	1641	8294A16	GEAR HOUSING ASSEMBLY, C	1		
7	43	41656T	GEAR, (16/27)	1		
7	43	41657T	GEAR, DRIVE (16/27)	1		