



2258

					Parts List			
Ref	Class	Part	Description	Qty	Comment	Footnote		
1	22	861150A	2 FITTING	1				
2	25	20195	1 O-RING, (.487 x .103)	2				
3	25	62702	1 O-RING, (.301 x .070)	1				
4	53	87843	1 E RING	1				
5	22	861163	1 QUICK CONNECTOR, (90 Degree)	1				
6	54	41582	5 CLAMP, Nylon	4				
7	32	19409	71 HOSE, (54.00 Inches Bulk)	2	(Cut to Length) (9.50 Inches) (36.0			
8	22	16739	1 CONNECTOR	1				
9	54	64235	1 J CLIP	1				
10	54	23567	1 CLIP	1				
11	10	60605	1 SCREW, (#10-16 X .750 Inch)	1				
12		69205	1 C WASHER	1				
13		806293T	1 BRACKET, Clip (3.0L/3.6L4.2L Die	1	(See Oil Reservoir Components Fo			
14		860065A	1 BRACKET KIT (3.0L/3.6L4.2L Dies	1	(See Oil Reservoir Components Fo			
15		806292T	1 BRACKET	1	(See Oil Reservoir Components Fo			
16		807025T	1 BRACKET	1	(See Oil Reservoir Components Fo			
17	16	805357	2 STUD, (.375-16 x 2.130) (4.3LX/5.7	2				
18	12	20553	2 WASHER, (.406 x .734 x .063)	2				
19	11	32219	2 NUT, (.375-16)	2				
20		806649T	1 BRACKET (262 Magnum EFI)	1	(See Oil Reservoir Components Fo			
21		806650T	1 BRACKET (5.7L/5.7LX/350 Magnu	1	(See Oil Reservoir Components Fo			
22		806193A33	1 MONITOR ASSEMBLY, Oil	1	(Fitting Pointing Toward Right Side			
22		806193A30	1 RESERVOIR	1	(Fitting Pointing Toward Left Side)			
22		806193A37	1 RESERVOIR	1	(Fitting Pointing Toward Front Side			
23	36	806727	1 CAP	1				
24	22	808624	1 CONNECTOR	1				
25		807839T	1 BRACKET (4.3LX/4.3LXH/262 Ma	1	(See Oil Reservoir Components Fo			
26	10	65746	1 SCREW AND LOCKWASHER, (.2E	1				
27	12	69057	1 WASHER, (.281 x .734 x .063) (4.3	1				
28	11	826708	8 NUT, (.250-20) (4.3LX/4.3LXH/262	1				
-		806054A	1 OIL RESERVOIR RELOCATION KI	1				
29		860065A	1 BRACKET KIT	1	(See Note) (5.7L/5.7LX/350 Magr			
30		808023T	1 STRAP, Bracket	1				
31		865175T	1 BRACKET (4.3L/5.0L/5.7L/350 M	1	(See Component Illustration)			
32	10	828552	1 SCREW, (.375-16 x .500)	1				
33	11	826709	8 NUT, (.250-20)	1				
34	22	865190	1 CONNECTOR, Female	1				
35	22	865191	1 FITTING, Male	1				