

**Diesel**

Model	Ref. No.	Ratio	Driveshaft Housing			Gear Housing		
			Gear Tooth Count	Gear Set Part Number	Driveshaft Housing Complete	Gear Tooth Count	Gear Set Part Number	Gear Housing Complete
<b>Bravo One X</b>								
Bravo One X w/DWP	1	1.36:1	29/27	43-858331A3	1589-8868H81	15/19	43-14063A1	1656-8866A63
Bravo One X w/DWP	2	1.50:1	32/27	43-858327A3	1589-8868H82	15/19	43-14063A1	1656-8866A63
Bravo One X w/DWP	3	1.65:1	30/23	43-858335A3	1589-8868H86	15/19	43-14063A1	1656-8866A63
<b>Bravo Two X</b>								
Bravo Two X	4	1.50:1	29/27	43-858331A3	1589-8868H81	18/25	(P)43-827304T (D)43-827303	1641-8294A19
Bravo Two X	5	1.65:1	32/27	43-858327A3	1589-8868H82	18/25	(P)43-827304T (D)43-827303	1641-8294A19
Bravo Two X	6	1.81:1	29/27	43-858331A3	1589-8868H81	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
Bravo Two X	7	2.00:1	32/27	43-858327A3	1589-8868H82	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
Bravo Two X	8	2.20:1	30/23	43-858335A3	1589-8868H86	16/27	(P)43-41656T (D)43-41657T	1641-8294A16
<b>Bravo Three X</b>								
Bravo Three X	9	1.36:1	29/27	43-858331A3	1589-8868H81	15/19	43-805448A1	1656-8866A37
Bravo Three X	10	1.50:1	32/27	43-858327A3	1589-8868H82	15/19	43-805448A1	1656-8866A37
Bravo Three X	11	1.65:1	32/27	43-858327A3	1589-8868H82	18/25	43-824517A1	1656-8866A36
Bravo Three X	12	1.81:1	29/27	43-858331A3	1589-8868H81	16/27	43-822535A1	1656-8866A35
Bravo Three X	13	2.00:1	32/27	43-858327A3	1589-8868H82	16/27	43-822535A1	1656-8866A35
Bravo Three X	14	2.20:1	30/23	43-858335A3	1589-8868H86	16/27	43-822535A1	1656-8866A35
Bravo Three X	15	2.43:1	30/23	43-858335A3	1589-8868H86	13/24	43-828336A1	1656-8866A51

1609

**Parts List**

Ref	Class	Part	Description	Qty	Comment	Footnote
-			NS NOT SHOWN, Bravo One X	-		
1	5	5232100NZ	END MODEL, Diesel Bravo I x 1.3	1	(Bravo One X) (With DWP) (1.36:1	
1	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
1	43	858331A 3	GEAR SET, (29/27)	1		
1	1656	<a href="#">8866A63</a>	GEAR HOUSING ASSEMBLY, C	1		
1	43	14063A 1	GEAR SET, (15/19)	1		
2	5	5232200NZ	END MODEL, Diesel Bravo I x 1.5	1	(Bravo One X) (With DWP) (1.50:1	
2	1589	<a href="#">8868H82</a>	DRIVESHAFT HOUSING ASSEM	1		
2	43	858327A 3	GEAR SET, (32/27)	1		
2	1656	<a href="#">8866A63</a>	GEAR HOUSING ASSEMBLY, C	1		
2	43	14063A 1	GEAR SET, (15/19)	1		
3	5	5232300NZ	END MODEL, Diesel Bravo I x 1.6E	1	(Bravo One X) (With DWP) (1.65:1	
3	1589	8868H86	DRIVESHAFT HOUSING ASSEM	1		
3	43	858335A 3	GEAR SET, (30/23)	1		
3	1656	<a href="#">8866A63</a>	GEAR HOUSING ASSEMBLY, C	1		
3	43	14063A 1	GEAR SET, (15/19)	1		
-			NS NOT SHOWN, Bravo Two X	-		
4		5332200NP	, Complete	1	(Bravo Two X) (1.50:1 Ratio)	
4	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
4	43	858331A 3	GEAR SET, (29/27)	1		
4	1641	8294A19	GEAR HOUSING ASSEMBLY, C	1		
4	43	827304T	GEAR, (18/25)	1		
4	43	827303	GEAR, DRIVE (18/25)	1		
5		5332300NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (1.65:1 Ratio)	
5	1589	<a href="#">8868H82</a>	DRIVESHAFT HOUSING ASSEM	1		
5	43	858327A 3	GEAR SET, (32/27)	1		
5	1641	8294A19	GEAR HOUSING ASSEMBLY, C	1		
5	43	827304T	GEAR, (18/25)	1		
5	43	827303	GEAR, DRIVE (18/25)	1		
6		5337400NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (1.81:1 Ratio)	
6	1589	8868H81	DRIVESHAFT HOUSING ASSEM	1		
6	43	858331A 3	GEAR SET, (29/27)	1		
6	1641	<a href="#">8294A16</a>	GEAR HOUSING ASSEMBLY, C	1		
6	43	41656T	GEAR, (16/27)	1		
6	43	41657T	GEAR, DRIVE (16/27)	1		
7		5337600NP	STERNDRIIVE UNIT, Complete	1	(Bravo Two X) (2.00:1 Ratio)	
7	1589	<a href="#">8868H82</a>	DRIVESHAFT HOUSING ASSEM	1		
7	43	858327A 3	GEAR SET, (32/27)	1		
7	1641	<a href="#">8294A16</a>	GEAR HOUSING ASSEMBLY, C	1		
7	43	41656T	GEAR, (16/27)	1		
7	43	41657T	GEAR, DRIVE (16/27)	1		