



5075

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-	1656	8866A80	GEAR HOUSING ASSEMBLY, (17,	1	(Bravo-I)	
-	1656	8866A81	GEAR HOUSING ASSEMBLY, (15,	1	(Bravo-I)	
-	1656	8866A61	GEAR HOUSING ASSEMBLY, (15,	1	(Bravo-I)	
-	1656	8866A82	GEAR HOUSING ASSEMBLY, (17,	1	(Bravo-I)	
-	1656	8866A83	GEAR HOUSING ASSEMBLY, (15,	1	(Bravo-I)	
-	1656	8866A62	GEAR HOUSING ASSEMBLY, (15,	1	(Bravo-I)	
1	1656	8866A17	GEAR HOUSING ASSEMBLY	1	(Bravo One Standard)	
1	1656	8866A54	GEAR HOUSING ASSEMBLY	1	(Bravo One With Low Water Pick-	
1	1656	8866A64	GEAR HOUSING ASSEMBLY	1	(Bravo One Dual Water Pick-Up)	
2	16	57920 3	STUD, (.437-14/.437-20 x 2.06	2		
3	25	33465	O-RING	1		15
4	26	45577 1	SEAL	1		15
5	26	805344	SEAL, (.625 Outside Diameter)	1		
6	31	86754T	BEARING ASSEMBLY, Roller	1		
7		76214Q 5	ANODIC PLATE ASSEMBLY	1		
8	13	806210	LOCKWASHER, (.437)	1		
9	10	806327	SCREW, (.437-14 x 1.750)	1		
10	15	92914A 1	SHIM KIT	AR		
11	31	66668A 1	BEARING ASSEMBLY, Tapered	1		
12	45	858517A 3	DRIVESHAFT ASSEMBLY, (16,	1		
13	31	815901	RACE, Bearing	1		
14	31	86748A 1	BEARING ASSEMBLY, Tapered	1		
15	14	86739	TAB WASHER	1		15
16	15	86749A 1	SHIM KIT	AR		
17	23	92916	SPACER	1		
18	25	20826	O-RING, (2.230 x .139)	1		
19		88243A 3	COUPLING ASSEMBLY	1		
20	53	88242	RING, Retaining	1		
21	43	818928A 2	GEAR SET, (15/19)	1		
21	43	840872A 1	GEAR SET, (15/17)	1		
21	43	840870A 1	GEAR SET, (17/18)	1		
22	12	805068	WASHER	1		
23	10	34353	SCREW, (.375-16 x 1.00)	1		
24	15	87157A 1	SHIM KIT	AR		
25	31	86752A 1	BEARING ASSEMBLY, Tapered	1		
26	44	840377T	PROPELLER SHAFT	1		
27	31	812767A 1	BEARING ASSEMBLY, Tapered	1		
28		67440T	LOAD RING	1		
29	12	42256	THRUST WASHER, (.105 Inch T	1		
30		840372A 2	CARRIER ASSEMBLY, Bearing	1		
31	25	21524	O-RING	1		15