

| Parts List | | | | | | |
|------------|-------|-----------|---------------------------------|-----|---------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| NS | 5 | 5F36201HH | STERNDRIVE, Bravo I XR SM (1.1E | 1 | | |
| NS | 5 | 5G36201HH | STERNDRIVE, Bravo I XR SM (1.1E | 1 | | |
| NS | 5 | 5F36211HH | STERNDRIVE, Bravo I XR SM (1.1E | 1 | | |
| NS | 5 | 5G36211HH | STERNDRIVE, Bravo I XR SM (1.1E | 1 | | |
| NS | 5 | 5F36801HH | STERNDRIVE, Bravo XR SM (1.2E | 1 | | |
| NS | 5 | 5G36801HH | STERNDRIVE, Bravo XR SM (1.2E | 1 | | |
| NS | 5 | 5F36811HH | STERNDRIVE, Bravo XR SM (1.2E | 1 | | |
| NS | 5 | 5G36811HH | STERNDRIVE, Bravo XR SM (1.2E | 1 | | |
| NS | 5 | 5F36901HH | STERNDRIVE, Bravo XR SM (1.3E | 1 | | |
| NS | 5 | 5G36901HH | STERNDRIVE, Bravo XR SM (1.3E | 1 | | |
| NS | 5 | 5F36911HH | STERNDRIVE, Bravo XR SM (1.3E | 1 | | |
| NS | 5 | 5G36911HH | STERNDRIVE, Bravo XR SM (1.3E | 1 | | |

NO IMAGE