



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	861150A	FITTING, Bulk Head	2		
2	25	20195	O-RING, (.487 x .103)	2		
3	25	62702	O-RING, (.301 x .070)	1		
4	53	87843	E RING	1		
5	22	861163	QUICK CONNECTOR, (90 Degree)	1		
6	54	41582	CLAMP, Nylon	4		
7	32	19409	HOSE, (.54.00 Inches Bulk)	2	(Cut To 9.50 Inch Length And 36.0	
8	22	16739	CONNECTOR	1		
9	54	64235	J CLIP	1		
10	54	23567	CLIP	1		
11	10	60605	SCREW, (#10-16 X .750 Inch)	1		
12		69205	C WASHER	1		
13		806293T	BRACKET, Clip (3.0L/3.6L4.2L Die	1	(See Oil Reservoir Components Fo	
14		860065A	BRACKET KIT (3.0L/3.6L4.2L Dies	1	(See Oil Reservoir Components Fo	
15		806292T	BRACKET	1	(See Oil Reservoir Components Fo	
16		807025T	BRACKET	1	(See Oil Reservoir Components Fo	
17	16	805357	STUD, (.375-16 x 2.130) (4.3LX/5.7	2	(Carb)	
18	12	20553	WASHER, (.406 x .734 x .063)	2		
19	11	32219	NUT, (.375-16)	2		
20		806649T	BRACKET (262 Magnum EFI)	1	(See Oil Reservoir Components Fo	
21		806650T	BRACKET (5.7L/5.7LX/350 Magnu	1	(See Oil Reservoir Components Fo	
22		806193A33	MONITOR ASSEMBLY, Oil	1	(Fitting Pointing Toward Right Side	
22		806193A30	RESERVOIR	1	(Fitting Pointing Toward Left Side)	
23	36	806727	CAP	1		
24	22	808624	CONNECTOR	1		
25		807839T	BRACKET	1	(See Oil Reservoir Components Fo	
26	10	65746	SCREW AND LOCKWASHER, (.25	1	(4.3LX/4.3LXH/262 Magnum EFI	
27	12	69057	WASHER, (.281 x .734 x .063)	1	(4.3LX/4.3LXH/262 Magnum EFI	
28	11	826708	NUT, (.250-20)	1	(4.3LX/4.3LXH/262 Magnum EFI	
NS		806054A	OIL RESERVOIR RELOCATION KI	1		
29		860065A	BRACKET KIT	1	(See Note) (5.7L/5.7LX/350 Magr	
30		808023T	STRAP, Bracket	1		