



18721

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	1589	8868G21	DRIVESHAFT HOUSING ASSEMB	1		
2	16	57920	3 STUD, (.437-14/.437-20 x 2.060)	4		
3		16755A	1 SEAL	1		3
4	25	45710	O-RING, (1.424 x .103)	1		3
5	31	815900	BEARING	1		
6	31	87156	BEARING ASSEMBLY, Roller	1		
7	25	62705	O-RING	1		3
8	23	861209A	1 BUSHING KIT	1		
9	26	12709	SEAL, Oil	1		3
10	22	67892A	1 FITTING KIT, Plug Fill/Drain	1		
11	12	19183	WASHER, Fiber	1		3
12		92068A	6 TOP COVER	1		
13	31	815900	BEARING	1		
14	31	87156	BEARING ASSEMBLY, Roller	1		
15	25	97387	O-RING	1		3
16	10	98794	SCREW, (.375-16 x 1.00)	4		
17	23	87560091	THRUST BEARING, (.091)	AR	(RED)	6
17	23	87560094	THRUST BEARING, (.094)	AR	(LIGHT BLUE)	6
17	23	87560097	THRUST BEARING, (.097)	AR	(GREEN)	6
18	24	17997A	1 SPRING KIT	1		3
19	31	86771	BEARING, Thrust	2		
20	43	856184A	1 GEAR SET (1.50:1 BRAVO I & III,	1	(27/32 TEETH)	
20	43	856186A	1 GEAR SET (1.36:1 BRAVO I & III,	1	(27/29 TEETH)	
20	43	856188A	1 GEAR SET (1.65:1 BRAVO I, 2.20:	1	(23/30 TEETH)	
21	31	86768A	2 THRUST BEARING ASSEMBLY	1		
22	52	807375A	2 CLUTCH ASSEMBLY	1	(Refer to Service Bulletin 2001-17	
23	24	93505	SPRING	2		
24	45	812773T	DRIVESHAFT	1		
25	23	86770	COLLAR	1		
26		97351	KEEPER	2		3
27	19	32297	PLUG	1		
28	12	91964	WASHER	4		
29	11	35053	NUT, (.437-20)	4		
30		808006	INSERT, Trim Adjustment	1		
-	26	16709A	2 SEAL KIT	1		