



12165

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		882481	STARTER ASSEMBLY	1		
2	12	882744	WASHER	1		
3	11	882340	NUT, (M8)	2		
4	16	882525	STUD	1		
5	87	882395	RELAY, Starter	1		
6		882454	SENSOR, Tach	1		
7	13	882342	LOCKWASHER	2		
8	10	882708	SCREW	1		
9	10	882290	SCREW, (M6x10)	2		
10	10	882313	SCREW, (M6x16)	1		
11	10	882622	SCREW, (M12x55)	1		
12	13	882637	LOCKWASHER	1		
13	12	882344	WASHER	1		
14		882571	ALTERNATOR ASSEMBLY	1		
15	12	882642	WASHER	1		
16	13	882636	LOCKWASHER	1		
17		882520	BRACKET, With Tensioner, Alterna	1		
18	11	882633	NUT, (M10)	1		
19	10	882307	SCREW, (M10x130)	1		
20	10	882327	SCREW, (M8x35), With Plain and L	1		
21	10	882316	SCREW, (M14x35)	1		
22	10	882317	SCREW, (M10x40)	3		
22	10	889900	SCREW, (M10x35)	3		
23	10	882417	SCREW, (M5x12)	1		
24	13	882634	LOCKWASHER	1		
25		882746	PROTECTOR	1		
26	11	882339	NUT	1		
27	54	882351	CLIP, Harness	1		
28		882561	BRACKET	1		
29	10	882323	SCREW, (M10x22), With Lockwast	4		
30	57	882531	BELT, Alternator Drive	1		
31		882466	PULLEY, Idler	1		
32	12	889902	WASHER	1		