



Fuel Injection Pump

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	854037	NUT, (M8)	7		
2	12	811409	WASHER	3		
3	16	854135	STUD, (M8 x 30)	3		
4	11	854137	NUT	1		
5	13	811482	LOCKWASHER	1		
6	27	801765017	GASKET	1		
7	28	854136	KEY	1		
8		854213001	PUMP, Injector	1		
9		896332122	FITTING, Fuel Return	1		
10	27	854142001	GASKET, Injector	4		
11	25	854143	O-RING	4		
12		855485002	PIPE, Oil	1		
13		854138001	INJECTOR	1		
14		889885	INJECTION NOZZLE	3		
15		889887	BRACKET, Injector Nozzle Hold Dc	4		
16	12	811455	WASHER	4		
17	12	811411	WASHER, Sealing	4		
18	22	879704	ADAPTOR, Injector Nozzle	4		
19	25	809963042	O-RING	10		
20	10	801761165	BOLT, Banjo (M8 x 1.00), Banjo	5		
21		801761163	CONNECTOR, Return	1		
22		803623001	VALVE, Fuel	1		
23	12	811407	WASHER	1		
24		896332123	ELECTRIC STARTER	1		
25	32	855484001	FUEL LINES, To Injectors	1		
26	84	896332124	WIRE	1		
27	11	855385	NUT, (M5)	1		
28		896332125	BRACKET	1		
29	10	896332042	SCREW, (M6 x 25)	2		