



9841

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	11	855385	NUT, (M5)	6		
2	11	854032	NUT, (M6)	7		
3		896332222	THROTTLE POSITION SENSOR	1		
4	10	855511	SCREW, (M6 x 20)	4		
5		854036	LEVER, TPS	1		
6	12	854029	WASHER	3		
7	11	854028	NUT, Lock	4		
8	16	854039	STUD, TPS Lever	1		
9		896332220	BRACKET	1		
10		896332221	BRACKET	1		
11		896332224	MOUNT	4		
12		896332225	CIRCUIT BREAKER, (5 AMP)	1		
13		896332226	CIRCUIT BREAKER, (20 AMP)	2		
14		896332227	CIRCUIT BREAKER, (70 AMP)	1		
15		896332228	POWER RELAY, (12 Volt)	2		
16		896332223	VIBRATION	4		
17		896332229	CONTROL UNIT	1	(200)	
18		896332230	CONTROL UNIT	1	(170)	
19	84	803625	FUSE ASSEMBLY	1		
20		896332231	ELECTRICAL BOX	1		
21	10	896332	BOLT	1		
22	10	896332104	BOLT	2		
23	56	42600A 3	CONTROLLER ASSEMBLY	1		
24		NA	NOT AVAILABLE	1		
25	84	860616002	HARNESS, (23 feet)	1		
26	16	854027	STUD, Remote Control Cable	1		
27	54	896332232	CLAMP, Cable	1		
28		896332233	SWIVEL ASSEMBLY	1		