



9847

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	22	855517	ELBOW, Transmission	2		
2		NA	NOT AVAILABLE	2		
3		NA	NOT AVAILABLE	2		
4	12	855516	WASHER	2		
5	22	803174	ELBOW, Transimssion Oil Cooler	2		
6	10	896332	BOLT	2		
7	54	815504272	CLAMP, Worm Gear	2		
8		NA	NOT AVAILABLE	1		
9		NA	NOT AVAILABLE	1		
10		NA	NOT AVAILABLE	1		
11		NA	NOT AVAILABLE	1		
12		865383A02	POWER STEERING ACTUATOR	1		
13	32	816172	HOSE	1		
14	54	896332085	CLAMP	2		
15	22	816339	NOZZLE	2		
16	35	860603	FILTER	1		
17	32	44348T	TUBE	1		
18		865380A25	TRIM PUMP ASSEMBLY, Comple	1		
19		805013T 1	PIPE, Exhaust	1		