



8564

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	23	811376	BEARING, Standard, Forward Main	1		
1	23	811377	BEARING, (.25mm), Forward Main	1		
2	43	896332010	GEAR, Crankshaft	1		
3	28	801331642	KEY	1		
4	486	884013001	CRANKSHAFT	1		
5	43	896332012	GEAR, Drive Balance	1		
6		803621	BEARING, Standard, Thrust	1		
6	23	884006	BEARING, (.10mm), Thrust	1		
6	23	884007	BEARING, (.20mm), Thrust	1		
7	23	884023	BEARING, (Standard), Rear Main	1		
7	23	884024	BEARING, (.20mm), Rear Main	1		
8	23	896314	BEARING, Standard, Center Main	1		
8	23	896332011	BEARING, (.25mm), Center Main	1		