



12819

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	32	805741	HOSE, Heat Exchanger to Thermostat	1	
2	54	815504220	CLAMP, Worm Gear	4	
3		854164	BRACKET, Heat Exchanger Support	1	
4		854165	LIFTING EYE	1	
5	10	854166	SCREW, (M10 x 35)	3	
6	13	40024 8	LOCKWASHER, (M10)	3	
7		805681	HOUSING, Thermostat	1	
8	10	40003 59	SCREW, (M8 x 60)	2	
9	10	40003 63	SCREW, (M8 x 100)	2	
10	13	40025 7	LOCKWASHER, (M8)	4	
11	27	805723	GASKET	1	5
12		805947T	THERMOSTAT, (160 Degree)	1	
13		805948	THERMOSTAT, (180 Degree)	1	
14		854168	COVER, Thermostat Housing	1	
15	10	40092 38	SCREW, (M6 x 80), Mount Cover	5	
16	16	854169	STUD, (M6 x 75)	1	
17	13	40025 6	LOCKWASHER, (M6)	6	
18	23	854170	SPACER, Engine Cover	1	
19	32	805744	HOSE, Thermostat Housing to Water	1	
20	32	805739	HOSE, Thermostat Housing to Heat Exchanger	1	
21	54	815504348	CLAMP, Worm Gear	2	
-	27	881742	OVERHAUL GASKET SET	1	