



18677

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	486	889864	CRANKSHAFT	1		
2	28	801331642	KEY	1		
3	43	889865	GEAR, Crankshaft	1		
4	23	811376	BEARING, Standard	1		
4	23	811377	BEARING, (.25mm)	AR		
4	23	811378	BEARING, (.50mm)	AR		
5	23	801331631	BEARING, Standard	4		
5	23	801331632	BEARING, (.25mm)	AR		
5	23	801331633	BEARING, (.50mm)	AR		
6		803621	BEARING, Standard, Front Thrust	1		
6	23	884006	BEARING, (.10mm), Front Thrust	AR		
6	23	884007	BEARING, (.20mm), Front Thrust	AR		
7	23	803622	WASHER, Rear Thrust	1		
8	23	884023	BEARING, (Standard)	1		
8	23	884024	BEARING, (.20mm)	AR		
8	23	884025	BEARING, (.50mm)	AR		
9		811379	FLANGE ASSEMBLY, Front	5		
10	17	801331647	PIN	10		
11	10	811382	SCREW, (M10 x 90)	10		
12	13	809932110	LOCKWASHER	10		
13		884026	FLANGE ASSEMBLY, Rear	1		
14	17	809941485	PIN	1		
15	16	811383	STUD, (M8 x 20)	6		
16	26	884027	SEAL	1		
17	25	801331654	O-RING	1		
18	12	40022 17	WASHER	6		
19	13	811384	LOCKWASHER, (M8)	6		
20	11	854037	NUT, (M8)	6		
-	27	881742	OVERHAUL GASKET SET	1		