



17088

Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		898272	COVER, Engine	1		
2	17	898272001	PIN, Engine Cover Mount	5		
3	10	896332	BOLT	5		
4		898272002	BRACKET, Engine Cover Mount	1		
5	23	896332040	SPACER	1		
6		898272003	BRACKET, Engine Cover Mount	1		
7	11	854037002	NUT, (M8)	3		
8	10	896332184	BOLT	2		
9	17	898272004	PIN, Engine Cover Mount	1		
10		898272005	BRACKET, Engine Cover Mount	1		

