



16980

Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	11	854037002	NUT, (M8)	7	
2		898272007	SUPPORT, Rubber	3	
3	11	854032	NUT, (M6)	10	
4	10	854118001	SCREW	1	
5		854035	TPS	1	
6	10	896332173	SCREW	2	
7		854036	LEVER, TPS	1	
8		889891	CONTROL UNIT	1	(300hp)
8		898248	CONTROL UNIT	1	(250hp)
8		898249	CONTROL UNIT	1	(270hp)
8		898250	CONTROL UNIT	1	(320hp)
9		898140	SUPPORT, Rubber	4	
10	12	854029	WASHER	3	
11	16	854027	STUD	1	
12	11	854028	NUT, Lock	4	
13	16	854039	STUD, TPS Lever	1	
14		898272008	BRACKET	1	
15		898272009	BRACKET	1	
16	10	898272010	SCREW	2	