



12823

Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	816248	PUMP ASSEMBLY, Seawater	1		
2	10	801332608	SCREW	6		
3		801332607	COVER	1		
4	27	801332606	GASKET	1		
5	47	816814T	IMPELLER	1		
6		816813	CAM	1		
7	12	801332601	WEAR PLATE	1		
8	53	816815	RING, Retaining	1		
9	23	816816	SPACER	1		
10		816817	SEAL	1		
11	26	816818	SEAL, Oil	1		
12	10	801332604	SCREW	1		
13	30	816819	BEARING, Ball	2		
14		816820	SHAFT	1		
15	25	801333850	O-RING	1		
16	13	811418	LOCKWASHER	4		
17	11	811417	NUT	4		
18	32	889897	HOSE, To Air Cooler	1		
19	54	815504220	CLAMP, Worm Gear	1		
20	32	896332091	HOSE, To Sea Water Filter	1		
21	54	815504232	CLAMP, Worm Gear, SS - Worm Ge	3		
22	32	816173	FITTING, Hose	1		
23	32	889500	HOSE	1		
24		99356A 2	COOLER	1		
25		889895	BRACKET, Fuel Cooler	1		
26	54	18904	CLIP	1		