



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1	12	830111240	BEARING SET-Thrust (For One En)	1	
2		837011770	BEARING SET-Main (For One Engi	1	
3		830112680	RING SET-Piston (For One Engine)	1	
4		832011570	BEARING SET-Conrod (For One Er	1	
5		832161781	PISTON	6	
6	41	832511300	PIN-Piston	6	
7		832601460	ROD ASSEMBLY-Connecting	6	
8		832651371	BOLT-Conrod	12	
9		832721290	BUSHING-Conrod Repair	6	
10		834081260	PULLEY-Crankshaft	1	
11		834111751	CRANKSHAFT	1	
12		834502492	FLYWHEEL ASSEMBLY	1	
13		834531270	RING GEAR-Flywheel	1	
14	10	834551100	BOLT-Flywheel	6	
15		835211110	GEAR-Crankshaft	1	
16	23	830116148	SPACER	1	
17	23	830129119	COLLAR	1	
18	11	830927103	NUT-Pulley	1	
19	28	833910111	KEY-Pulley	1	
20	53	831937102	RING-Piston Pin Retaining	12	
21	25	835141101	O-RING	1	