



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		830121231	COVER ASSEMBLY-Oil Pump	1		
2	43	834999992	GEAR ASSEMBLY-Oil Pump	1		
3		831101541	PUMP ASSEMBLY-Oil	1		
4		831141050	GUIDE-O-Ring	1		
5	27	831191121	GASKET-Cover	1		
6		834011520	PICK-UP ASSEMBLY-Oil Pump	1		
7		836003490	BASE ASSEMBLY-Oil Filter	1	SEE OIL FILTER BASE ASSEMBLY	
8		837101810	COOLER ASSEMBLY-Oil	1	SEE OIL COOLER ASSEMBLY	
9		835818181	PLATE-Caution	1		
10	22	830235130	CONNECTOR	1		
11	10	831914237	BOLT-Connector	11		
12	10	838108200	BOLT-Cover	5		
13		838108350	BOLT-Cover	2		
14		838908110	BOLT-Pick-Up Bracket	1		
15		838108300	BOLT-Pick-Up	1		
16		838108500	BOLT-Pick-Up	1		
17	10	839108401	BOLT-Oil Cooler	8		
18		839108551	BOLT-Oil Cooler	2		
19		839108752	BOLT-Filter Base	1		
20		839108002	BOLT-Filter Base	2		
21		839908157	BOLT-Filter Base	3		
22		830410110	PLUG-Filter Base	1		
23	19	832910115	PLUG-Connector	3		
24	25	834402135	O-RING-Pick-Up	1		
25	12	835914110	WASHER-Sealing	3		
26	12	835910105	WASHER-Sealing	1		
27	25	835119101	O-RING-Oil Cooler & Base	8		