



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		863914T	HOUSING-Flywheel	1		1
2		52158A20	BRACKET-Rear Mount	2		
3	13	40024 8	LOCKWASHER	8		
4	10	40001197	SCREW-(M10 x 35)	4		
5		864912A 1	MOUNT-Rear	2		1
6	11	20739	NUT-(.750-16)	2		
7	14	66658	WASHER-Tab	1		
8	13	68102	LOCKWASHER	1		
9		66166A 4	TRUNNION	1		
10	54	47528	CLAMP	4		
11	13	32993	LOCKWASHER	2		
12	10	47724	SCREW-(.437-14 x 3 In.)	2		
13	11	29553	NUT	2		
14		864890T	DRIVE PLATE-Centra	1		1
15	13	864918	LOCKWASHER	6		1
16	10	864917	SCREW-(M7-1 x 30)	6		1
17		817416A 4	BEARING SUPPORT HOUSING-C	1		
18	30	860081	BEARING-BALL	1		
19	23	817417	SPACER-Bearing	1		
20	30	93944	BEARING-Ball	1		
21	26	93924	SEAL-Grease	1		
22		817415T	SHAFT-Input	1		1
23	19	93921	PLUG-Expansion	1		
24	53	93914	RING-Retaining	1		
25	53	93915	RING-Retaining	1		
26	10	76926	SCREW-(.375-16 x .88)	3		
27		93918A 1	SHEILD-Lower	1		
28	10	57053	SCREW-(.50-20 x 4.50)	2		
29	12	42307	WASHER	4		
30	13	35777	LOCKWASHER	2		
31	11	826708 17	NUT	2		
32		93919A 1	SHEILD-Upper	2		
33	10	76926	SCREW-(.375-16 x .88)	8		
34	11	806709 12	NUT	8		1
35		864519T01	ADAPTOR- Double Bearing	1		1
36	22	74036	FITTING-Grease	1		
37		807317T	SHAFT-Tailstock	1		1
38	25	29845	O-RING	4		
39	30	62780T	BEARING-Ball	2		
40	53	94104	RING-Retainer	2		
41	53	941997T	RING-Retainer	1		