



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1	431	882443	CAMSHAFT	1	(Intake)	
2	431	882675	CAMSHAFT	1	(Exhaust)	
3		882485	PIN-Camshaft (Exhaust Only)	1		
4		882477	VALVE-Intake	8		
5		882473	VALVE-Exhaust	8		
6	12	882362	WASHER	1		
7	43	882480	GEAR-Camshaft	1		
8		882486	PIN-Gear Set	1		
9	10	882427	SCREW-Cam Pulley (M12 x 47)	1		
10	25	882367	SEAL-Oil Camshaft, Front	1		
11	10	882626	SCREW-Flange w/ Washer (M4 x 8)	1		
12		882445	FLANGE-Cam Pulley	1		
13	12	882450	WASHER_Gear Cam	1		
14		882483	COLLAR-Split	32		
15	24	882490	SPRING-Valve	16		
16		882482	SEAT-Spring	16	(Upper)	
16		882487	SEAT-Spring	16	(Lower)	
17		882252	ADJUSTER-Valve Gap	16	(T=2.70)	
17		882253	ADJUSTER-Valve Gap	16	(T=2.72)	
17		882254	ADJUSTER-Valve Gap	16	(T=2.74)	
17		882255	ADJUSTER-Valve Gap	16	(T=2.76)	
17		882256	ADJUSTER-Valve Gap	16	(T=2.78)	
17		882257	ADJUSTER-Valve Gap	16	(T=2.80)	
17		882258	ADJUSTER-Valve Gap	16	(T=2.82)	
17		882259	ADJUSTER-Valve Gap	16	(T=2.84)	
17		882260	ADJUSTER-Valve Gap	16	(T=2.86)	
17		882261	ADJUSTER-Valve Gap	16	(T=2.88)	
17		882262	ADJUSTER-Valve Gap	16	(T=2.90)	
17		882263	ADJUSTER-Valve Gap	16	(T=2.92)	
17		882264	ADJUSTER-Valve Gap	16	(T=2.94)	
17		882265	ADJUSTER-Valve Gap	16	(T=2.96)	
17		882266	ADJUSTER-Valve Gap	16	(T=2.98)	
17		882267	ADJUSTER-Valve Gap	16	(T=3.00)	
17		882268	ADJUSTER-Valve Gap	16	(T=3.02)	
17		882269	ADJUSTER-Valve Gap	16	(T=3.04)	
17		882270	ADJUSTER-Valve Gap	16	(T=3.06)	
17		882271	ADJUSTER-Valve Gap	16	(T=3.08)	
17		882272	ADJUSTER-Valve Gap	16	(T=3.10)	
17		882273	ADJUSTER-Valve Gap	16	(T=3.12)	
17		882274	ADJUSTER-Valve Gap	16	(T=3.14)	
17		882275	ADJUSTER-Valve Gap	16	(T=3.16)	