



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		807261	HEAT EXCHANGER	1		
2	36	808108	CAP-FILLER	1		
		806000	ANODE	1		
	10	88743	SCREW-OIL COOLER END PLA	2		
		806002A	END PLATE-OIL COOLER	2		
	27	806882	GASKET-OIL COOLER END PI	2		
	10	846109	SCREW- HEAT EXCHANGER	2		
		860319A	END COVER-EXCHANGER	2		
	27	806883	GASKET-HEAT EXCHANGER	2		
3	54	884016	CLAMP	2	(2.8L)	
3	54	855491	CLAMP	2	(4.2L)	
4	54	815504220	CLAMP	1	(2.8L)	
5	32	805743	HOSE-HEAT EXCHANGER TO W	1		
6	54	815504232	CLAMP	2		
7	32	805740	HOSE-OIL COOLER TO AIR COOL	1		
8	54	815504228	CLAMP	1		
9	10	809919131	PLUG-HOT WATER HEATER	1		
10	12	809963354	WASHER-SEALING	1		2,3,4,5
11	37	861455	DECAL	1	(2.8L)	
11	37	861454	DECAL	1	(4.2L)	
12	32	806548440	HOSE (Cut to Length)	2	4.2L (DESIGN 1) MIE	
13		63832A	COOLER-TRANS. OIL	1	4.2L (DESIGN 1) MIE	
14	54	815504220	CLAMP-HOSE	4	4.2L (DESIGN 1) MIE	
15	54	18904	CLIP	2	4.2L (DESIGN 1) MIE	
16		801761589	BRACKET	2	4.2L (DESIGN 1) MIE	
17	10	40071	SCREW	2	4.2L (DESIGN 1) MIE	
18	11	40021	NUT	2	4.2L (DESIGN 1) MIE	
19		805324	STUD-EXTENSION	2	4.2L (DESIGN 1) MIE	
20	11	40138	NUT	2	4.2L (DESIGN 1) MIE	
21	32	855492	HOSE (2.8L)	1	2.8L AND 4.2L STERN DRIVE	
21	32	806548440	HOSE (4.2L)	1	2.8L AND 4.2L STERN DRIVE	
22	32	855493	HOSE (2.8L)	1	2.8L AND 4.2L STERN DRIVE	
22	32	807423	HOSE (4.2L)	1	2.8L AND 4.2L STERN DRIVE	
23	32	807001	HOSE-COOLER TO EXH. ELBOW	1	2.8L AND 4.2L STERN DRIVE	
24		99356A	COOLER-POWER STEERING OIL	1	2.8L AND 4.2L STERN DRIVE	
25	54	18904	CLIP	2	2.8L AND 4.2L STERN DRIVE	
26	54	815504220	CLAMP-HOSE	4	2.8L AND 4.2L STERN DRIVE	
27	32	803172	HOSE-EXCHANGER TO HOSE IN:	1	2.8L AND 4.2L (DESIGN 2) MIE	
27	32	855495	HOSE-EXCHANGER TO HOSE IN:	1	2.8L AND 4.2L (DESIGN 2) MIE	
28		855498	INSERT-HOSE	1	2.8L AND 4.2L (DESIGN 2) MIE	
29	32	803171	HOSE-INSERT TO TRANS. OIL CI	1	2.8L AND 4.2L (DESIGN 2) MIE	