


FLYWHEEL HOUSING/DRIVE PLATE



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		801331695	FLYWHEEL HOUSING	1		
2	16	809908402	STUD	2		
3	13	811408	LOCKWASHER	2		
4	11	811458	NUT	2		
5	25	801331619	O-RING	1		1
6	10	809913834	SCREW	9		
7	13	809932112	LOCKWASHER	9		
8	12	811459	WASHER	9		
9	265	811453	FLYWHEEL	1		
10	43	801331701	RING GEAR	1		
11		801331697	GUIDE RING	1		
12	25	811498	O-RING	1		1
13	10	801331698	SCREW	1		
14	10	811454	BOLT	6		
15		816830	BRACKET	1		
16	10	811457	SCREW	1		
17	13	809932110	LOCKWASHER	1		
18	10	811456	SCREW	2		
19	13	809932095	LOCKWASHER	2		
20	12	811455	WASHER	2		
21		816170	DRIVE PLATE (DRIVE PLATE)	1		
22	10	809913815	SCREW (10MM) (DRIVE PLATE)	6		
23		805045A 3	COUPLER ASSEMBLY (2 STAGE)	1		
24	10	805109 15	SCREW (2 STAGE COUPLER)	4		
25		805110	SNUBBER (2 STAGE COUPLER)	4		
26	10	40001192	SCREW (2 STAGE COUPLER)	6		
27	13	40024 8	LOCKWASHER (2 STAGE COUPLER)	6		
28		815928	HOUSING	1		
29	10	40001206	SCREW (50MM)	7		
29	10	40001203	SCREW (45MM)	1		
30	13	809931076	LOCKWASHER	8		
31	27	811490	GASKET SET			