


INJECTION PUMP



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1		816550	INJECTION PUMP	1		
2	27	801765017	GASKET	1		1
3	16	811402	STUD	3		
4	12	811409	WASHER	3		
5	13	811384	LOCKWASHER	3		
6	11	811400	NUT	3		
7	28	811404	KEY	1		
8	13	811408	LOCKWASHER	1		
9	11	811403	NUT	1		
10		811406	FUEL SHUT-OFF	1		
11	12	811407	WASHER	1		
12		801333856	TRACTION ROD	1		
13	17	809987302	BALL PIN	1		
14	12	809931036	WASHER	2		
15	11	809922410	NUT	1		
16		801761674	BEARING ANGLE	1		
17	10	809913466	SCREW	2		
18	12	809931652	WASHER	2		
19		801763525	LEVER	1		
20	23	801256320	BUSHING	2		
21	13	809932095	LOCKWASHER	1		
22	13	809932646	LOCKWASHER	1		
23	53	809932852	E-RING	1		
24	11	809922038	NUT	1		
25		801763441	SUPPORT ANGLE	1		
26	10	801761847	SCREW	2		
27	16	38525	STUD	1		
28	12	24664	WASHER	3		
29	11	35888	NUT	2		
30	16	96112	STUD	1		
31	12	24664	WASHER	3		
32	11	35888	NUT	2		
33	32	801763467	BOOST PRESSURE TUBE	1		
34	10	801333874	BANJO BOLT	1		
35	12	809963072	WASHER	2		
36	54	801761758	CLAMP	1		
37	10	809913218	SCREW	2		
38	13	809932047	LOCKWASHER	2		
39	11	809922038	NUT	1		
40		801761757	SUPPORT	1		
41	22	801222872	CONNECTOR	1		