


**INSTRUMENT PANEL**



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
-		801764122	INSTRUMENT PANEL ASSEMBLY	AR	QUANTITIES: (STRN DRV) - 1; (II	
-		801764123	INSTRUMENT PANEL ASSEMBLY	AR	QUANTITIES: (STRN DRV) - ; (IN	
1	10	809902520	SCREW	AR	QUANTITIES: (STRN DRV)-20; (II	
2	87	801334117	IGNITION SWITCH (SEE CHART)	AR	QUANTITIES: (STRN DRV) - 1; (II	
3		801334100	INSTRUMENT PANEL	AR	QUANTITIES: (STRN DRV) - 1; (II	
4	87	816401	CIRCUIT BREAKER	AR	QUANTITIES: (STRN DRV) - 1; (II	
5		801334308	COVER	AR	QUANTITIES: (STRN DRV) - 1; (II	
6	79	801334121	WATER TEMPERATURE GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
7	79	801334120	VOLTMETER GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
8	79	817489	TACHOMETER GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
9	79	801334126	OIL TEMPERATURE GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
10	79	801334125	OIL PRESSURE GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
11		809978254	LIGHT BULB	AR	QUANTITIES: (STRN DRV) - 6; (II	
11		809978254	LIGHT BULB	AR	QUANTITIES: (STRN DRV) - 6; (II	
12		802982204	SOCKET	AR	QUANTITIES: (STRN DRV) - 6; (II	
12		802982204	SOCKET	AR	QUANTITIES: (STRN DRV) - 6; (II	
13	87	801334110	START SWITCH	AR	QUANTITIES: (STRN DRV) - 1; (II	
14	87	801334114	STOP SWITCH	AR	QUANTITIES: (STRN DRV) - 1; (II	
15		816404	PREHEATER INDICATOR LAMP	AR	QUANTITIES: (STRN DRV) - 1; (II	
16		816402	CHARGING INDICATOR LAMP	AR	QUANTITIES: (STRN DRV) - 1; (II	
17		816403	OIL PRESSURE WARNING LAMP	AR	QUANTITIES: (STRN DRV) - 1; (II	
18		801334113	TOUCH CONTACTOR	AR	QUANTITIES: (STRN DRV) - 3; (II	
19	84	801764124	HARNESS	AR	QUANTITIES: (STRN DRV) - 1; (II	
20	87	801764125	TRAILERING SWITCH	AR	QUANTITIES: (STRN DRV) - 1; (II	
21	87	801334110	COVER	AR	QUANTITIES: (STRN DRV) - 3; (II	
22		801334124	INSTRUMENT PANEL	AR	QUANTITIES: (STRN DRV) - 3; (II	
23		801334129	BUZZER	AR	QUANTITIES: (STRN DRV) - 1; (II	
24	79	812391	TRIM INDICATOR GAUGE	AR	QUANTITIES: (STRN DRV) - 1; (II	
25	84	812694	OVERRIDE HARNESS	AR	QUANTITIES: (STRN DRV) - 1; (II	
26		813905	INSTRUMENT PANEL	AR	QUANTITIES: (STRN DRV) - 1; (II	
27	19	801334216	COVER	AR	QUANTITIES: (STRN DRV) - ; (II	
28	19	812390	PLUG	AR	QUANTITIES: (STRN DRV) - ; (II	
29	32	801764018	HARNESS	AR	QUANTITIES: (STRN DRV) - 1; (II	
		801334401	KEY 93401	.		
		801334402	KEY 93402	.		
		801334403	KEY 93403	.		
		801334404	KEY 93404	.		
		801334405	KEY 93405	.		
		801334406	KEY 93406	.		
		801334407	KEY 93407	.		
		801334408	KEY 93408	.		