


**FLYWHEEL HOUSING/DRIVE PLATE**



Parts List					
Ref	Class	Part	Description	Qty	Footnote
1		801331695	FLYWHEEL HOUSING	1	
2	16	809908402	STUD	2	
3	13	811408	LOCKWASHER	2	
4	11	811458	NUT	2	
5	25	801331619	O-RING	1	1
6	10	809913834	SCREW	9	
7	13	809932112	LOCKWASHER	9	
8	12	811459	WASHER	9	
9	265	811453	FLYWHEEL	1	
10	43	801331701	RING GEAR	1	
11		801331697	GUIDE RING	1	
12	25	811498	O-RING	1	1
13	10	801331698	SCREW	1	
14	10	811454	BOLT	6	
15		816830	BRACKET	1	
16	10	811457	SCREW	1	
17	13	809932110	LOCKWASHER	1	
18	10	811456	SCREW	2	
19	13	809932095	LOCKWASHER	2	
20	12	811455	WASHER	2	
21		816170	DRIVE PLATE (DRIVE PLATE)	1	
22	10	809913815	SCREW (10MM) (DRIVE PLATE)	6	
23		805045A 3	COUPLER ASSEMBLY (2 STAGE)	1	
24	10	805109 15	SCREW (2 STAGE COUPLER)	4	
25		805110	SNUBBER (2 STAGE COUPLER)	4	
26	10	40001192	SCREW (2 STAGE COUPLER)	6	
27	13	40024 8	LOCKWASHER (2 STAGE COUPLER)	6	
28		815928	HOUSING	1	
29	10	40001206	SCREW (50MM)	7	
29	10	40001203	SCREW (45MM)	1	
30	13	809931076	LOCKWASHER	8	
31	27	811490	GASKET SET		