



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		18900A	TRANSMISSION (1.5:1 RATIO)	1	DOWN ANGLE	
1		18901A	TRANSMISSION (2.0:1 RATIO)	1	DOWN ANGLE	
1		18902A	TRANSMISSION (2.5:1 RATIO)	1	DOWN ANGLE	
1		814437A	TRANSMISSION (1.5:1 RATIO)	1	V-DRIVE	
1		814438A	TRANSMISSION (2.0:1 RATIO)	1	V-DRIVE	
1		814439A	TRANSMISSION (2.5:1 RATIO)	1	V-DRIVE	
2	16	91000	STUD	2		
3	11	809922113	NUT	2	(REFER TO NOTE 1)	
4	10	809913837	SCREW	2	(REFER TO NOTE 1)	
5		806238	BRACKET	1		
6	10	809919969	SCREW	2		
7	13	40024	LOCKWASHER	2		
8	16	97477A	STUD KIT	2		
9	87	88031	SWITCH-TEMPERATURE	1		1
10	22	855517	ELBOW-TRANSMISSION	2		1
11	12	855516	WASHER-SEALING	2		1
12	32	855518	OIL HOSE (850 MM)	1		1
12	32	855519	OIL HOSE (930 MM)	1		1
13	22	803174	ELBOW-TRANSMISSION OIL COC	2		
14		79476A	FLANGE ASSEMBLY	OPT	(1 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(1-1/8 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(1-1/4 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(1-3/8 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(1-1/2 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(1-3/4 IN.)	6
14		79476A	FLANGE ASSEMBLY	OPT	(2 IN.)	6
15	10	60171	SCREW-FLANGE	2	(1-1/4 IN.)	
15	10	60169	SCREW-FLANGE	2	(3/4 IN.)	
16	10	805159	SCREW-FLANGE (1-1/2 IN.)	4		
17	13	32993	LOCKWASHER	4		
18	11	22024	NUT	4		