

NO IMAGE

| Parts List | | | | | | |
|------------|-------|-----------|--------------------------|-----|------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| | | 806386 | PANEL | 1 | | |
| | 87 | 805675A 1 | SWITCH-AUDIO/PANEL LIGHT | 1 | | |
| | 87 | 805676A 1 | SWITCH-START | 1 | | |
| | 87 | 805676A 1 | SWITCH-STOP | 1 | | |
| | 84 | 860618 | HARNES-INSTUMENT | 1 | | |
| | 84 | 860615 | HARNES-EXTENTION | 1 | (4 METERS) | |
| | 84 | 860617 | HARNES-"Y" | 1 | | |
| | | 49734 | SENDER-TEMPERATURE | 1 | | |
| | | 805268 | SENDER-OIL PRESSURE | 1 | | |