



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		854057	ROCKER ARM ASSEMBLY	6		
2		854059	ROCKER ARM (INTAKE)	6		
3		854060	SUPPORT-ROCKER ARM	6		
4		854061	ROCKER ARM (EXHAUST)	6		
5	23	854062	BUSHING	12		
6	11	854037	NUT (M8)	12		
7		854058T	BRACKET-ROCKER ARM	6		
8		854063	LIFTER-ROLLER	12		
9		854064	PUSH ROD	12		
10		854066	BRACKET-LIFTER RETAINER	6		