



| Parts List | | | | | | |
|------------|-------|-----------|-------------------|-----|------------------|----------|
| Ref | Class | Part | Description | Qty | Comment | Footnote |
| 1 | | 805884T | ALTERNATOR | 1 | (PRESTOLITE) | |
| 1A | | 805884T | ALTERNATOR | 1 | (MANDO) | |
| 2 | | 801763465 | SUPPORT | 1 | | |
| 3 | 10 | 809912567 | SCREW | 1 | | |
| 4 | 12 | 40022 17 | WASHER | 1 | | |
| 5 | 11 | 815088 | NUT | 1 | | |
| 6 | 10 | 806622 | SCREW | 1 | | |
| 7 | 13 | 811482 | LOCKWASHER | 2 | | |
| 8 | 12 | 811480 | WASHER | 2 | | |
| 9 | 16 | 806620 | STUD | 1 | | |
| 10 | 11 | 811478 | NUT | 1 | | |
| 11 | 57 | 44207 | V BELT | 1 | | |
| 12 | | 806422 | BRACE | 1 | | |
| 13 | 10 | 35386 | SCREW | 1 | | |
| 14 | 13 | 53166 | LOCKWASHER | 1 | | |
| 15 | 12 | 814806 | WASHER | 1 | | |
| 16 | 10 | 40001206 | SCREW | 1 | | |
| 17 | 12 | 40023 20 | WASHER | 1 | | |
| 18 | 11 | 40136 10 | NUT | 1 | | |
| 19 | | 816543 | SPACER | 2 | | |
| 19 | 23 | 32727 | SPACER | 1 | | |
| 21 | 12 | 96457 | WASHER | 1 | MANDO ALTERNATOR | |
| 22 | 13 | 26992 | LOCKWASHER (#1/4) | 1 | MANDO ALTERNATOR | |
| 23 | 11 | 94330 | NUT (1/4 - 20) | 1 | MANDO ALTERNATOR | |
| 24 | 13 | 26996 | LOCKWASHER (#10) | 2 | MANDO ALTERNATOR | |
| 25 | 11 | 79989 | NUT (10 - 24) | 2 | MANDO ALTERNATOR | |