



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		854057	ROCKER ARM ASSEMBLY	4/6		
2		854059	ROCKER ARM (INTAKE)	4/6		
3		854060	SUPPORT-ROCKER ARM	4/6		
4		854061	ROCKER ARM (EXHAUST)	4/6		
5	23	854062	BUSHING	8/12		
6	11	854037	NUT (M8)	8/12		
7		854058T	BRACKET-ROCKER ARM	4/6		
8		854063	LIFTER-ROLLER	8/12		
9		854064	PUSH ROD	8/12		
10		854066	BRACKET-LIFTER RETAINER	4/6		