



Parts List

Ref	Class	Part	Description	Qty	Comment	Footnote
1	46	855502	PUMP ASSEMBLY-SEAWATER	1		
2	10	801332608	SCREW	6		
3		801332607	COVER	1		
4	27	801332606	GASKET	1		
5	47	801332602	IMPELLER	1		
6		814873	CAM	1		
7	26	801332600	SEAL-OIL	2		
8		801332599	SPREADER	1		
9	25	801332598	O-RING	1		
10	12	801332601	WASHER-THRUST	1		
11	17	801332620	PIN	1		
12	10	801332604	SCREW	1		
13	30	801330116	BEARING-BALL	2		
14		801332599	SPACER	1		
15	53	801332595	RING-RETAINING	1		
16	45	801332593	SHAFT	1		
17	25	801333850	O-RING	1		
18	11	40021	NUT (M6)	2		
19	32	805375	HOSE	1		
20	54	815504220	CLAMP	2		
21	54	815504228	CLAMP	1		
22	32	806441	HOSE	1		
23	54	815504232	CLAMP	1		
24	32	816173	REDUCER-HOSE	1		