



Parts List						
Ref	Class	Part	Description	Qty	Comment	Footnote
1		854025	BRACKET-CONTROL UNIT	1		
2		854026	BRACKET-REMOTE CONTROL C	1		
3	16	854027	STUD-REMOTE CONTROL CABLE	1		
4	11	854028	NUT-LOCK	4		
5	12	854029	WASHER	3		
6		855510	CONTROL UNIT	1	(2.8L)(750 RPM)(0L343084 and be	
6		881308	CONTROL UNIT	1	(2.8L)(600 RPM)(0L343085 and up	1
6		854030	CONTROL UNIT	1	(4.2L)(750 RPM)(0L343703 and be	
6		881309	CONTROL UNIT	1	(4.2L)(600 RPM)(0L343704 and up	1
7		854031	SUPPORT-RUBBER	3		
8	11	854032	NUT (M6)	10		
9	10	855511	SCREW (M6 X 20)	8		
10		854034	BRACKET-UPPER CONTROL UNI	1		
11		854035	TPS	1		
12		854036	LEVER-TPS	1		
13	11	854037	NUT (M8)	1		
14		854038	SUPPORT-CONTROL UNIT BRAC	1	(STERN DRIVE)	
14		860598	SUPPORT-CONTROL UNIT BRAC	1	(INBOARD)	
15	16	854039	STUD-TPS LEVER	1		